



User Manual MODEL: MBH30

Thank you for purchasing Mpow Antelope Stereo Bluetooth Headset. We hope you enjoy it! This instruction manual will get you to understand and make the most of your headset.

IN THE BOX









0




BLUETOOTH HEADSET X1 EARTIPS (S) X2 USB CABLE X1

USER GUIDE X1

EARTIPS (M) X2

EARTIPS (L) X2

PRODUCT INDICATION



SPECIFCATION

Bluetooth Standard	V4.1
Bluetooth Operation	Class 2
Bluetooth Mode	Headset/Handfree/A2DP/AVRCP
Bluetooth Range	>10m
Talking Time	Up to 8 hours
Playing Time	Up to 8 hours
Stand By Time	240 hours
Charging Time	2 hours

②


CHARGING THE HEADSET

Charging the headset before use is recommended but not required. Every Mpow Antelope headset is pre-charged before it leaves the factory.





PAIR IT TO YOUR PHONE



- 1. Before using the headset for the first time, you must pair it with your phone.
- 2. Turn on the Bluetooth function on your phone.
- 3. Press the Multifunction button for 7 seconds until The white light flashes quickly flashing alternately, you will also hear a voice prompting "Pairing".
- 4. Search Bluetooth devices and select " Mpow Antelope " on your phone. Enter passcode 0000 if needed.





- If pairing is successful, the white indicator light will start flashing slowly, you will also hear a voice prompting " Connected"
- 6. Paring failed: Please turn off your headset and then repeat the steps outlined above.
- Automatic Connect: It will connect to the last connected phone automatically when it turns on. Please make sure the Bluetooth function of your phone is on before turning on the headset. If not, it won't connect to the last connected phone automatically.

POWER ON / OFF THE HEADSET

Power on

Press the Multifunction button for 4 seconds until the white indicator light flashing, you will also hear a voice prompting "Power On".

Power off

Press the Multifunction button for 4 seconds until the orange indicator light turns on and then goes off, you will also hear a voice prompting "Power Off".

CONNECT TO TWO BLUETOOTH DEVICES AT THE SAME TIME

- 1. Pair the Bluetooth headset to the first phone.
- After a successful pairing, turn off the headset, and also turn off the Bluetooth function on the first phone.
- 3. Pair the Bluetooth headset to the second phone.
- After a successful pairing, turn on the Bluetooth function of the first phone. Select the "Mpow Wolverine" and click
 "connect"

 "connect"

 "Tonnect"

 "Tonnect"
- 5. Two phones will both be connected to the headset at the same time.

ANSWERING A CALL

Press the Multifunction button.

ENDING A CALL

Press the Multifunction button.

REJECTING A CALL

Press the Multifunction button until you hear a voice prompting "toot toot" and then release.

REDIALING THE LAST CALLED NUMBER

Double press the Multifunction button.

VOICE DIAL

Press the Multifunction button and "+" button simultaneously, please make sure your phone support this function.

MICROPHONE MUTING

During a call, press the " MFB " and "—"button simultaneously and you will hear a low tone alert to confirm that the headset MIC is in mute status.

0

PLAYING MUSIC

- 1.Play/Pause: Press the Multifunction button.
- 2. Next Song: Long press the " \pm " button.
- 3. Previous Song: Long press the "-" button.
- 4. Volume Up: Short press the " + " button.
- 5. Volume Down: Short press the "- " button.

FAQ:

Q: Why can't turn on the headset?

A: Make sure your device is fully charged before using it for the first time. Your device can not be turned on if battery level is very low.

Q: There is no sound when playing?

A: Check whether the connection between your device and your headset is OK. If they are disconnected, please re-connect them. And adjust the volume level to a suitable level.

Q: Phone or computer can't find your device?

A: Check whether the Bluetooth headset is in pairing mode. If the Bluetooth headset hasn't been paired for long time, pairing mode will shut off automatically, please re-open it. If your phone is malfunction, please re-start the phone. If your Bluetooth headset is malfunction, please re-start or reset it.

CORRECT DISPOSAL OF THIS PRODUCT

(Waste Electrical & Electronic Equipment) This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environmentor human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.







0



